


CattleMaster 840 Constant Flow

Part # 18263



Item	Part #	Description	Qty
1	18240	Casing Poly	1
2	16786	SS Trough w/ Screws & Nuts Pkg.	1 Pkg.
3	18241	Frame Poly	1
4	18428	Cover Poly	1
5	16621	Access Panel 8" Poly	2
6	18147	Access Panel Hardware Pkg.	2 Pkg.
7	18318	Bolt Down Washer (4/Pkg.)	2 Pkg.
8	16478	Plug #13-1/2 Pkg.	1 Pkg.
9	17679	Bulkhead Fitting 2"	1
10	12154	Overflow Pipe 2" - Constant Flow	1
11	18181	Standpipe w/ Washer & Nut Pkg.	1 Pkg.
12	18317	Quick Release Pins SS (2/Pkg.)	1 Pkg.
13	18316	Fenwal Replacement Plug Pkg.	1 Pkg.
14	18314	Float w/ Hardware Pkg.	1 Pkg.
	18313	Hardware for Float Pkg.	1 Pkg.
15	11514	Cattle Valve 3/4" Bracket Pkg.	1 Pkg.
16	16891	Constant Flow w/ Petcock Pkg.	1 Pkg.
-or-	11142	Constant Flow w/o Petcock Pkg.	1 Pkg.
17	18265	Carriage Bolt & Nut SS (5/Pkg.)	1 Pkg.
18	18266	Screw & Nut for Frame SS	1 Pkg.
NS	12583	Cattle Valve Supply Line Pkg.	1 Pkg.
NS	11793	Petcock Valve (1/Pkg.)	1 Pkg.
NS	18332	Accessory Pkg.	1 Pkg.

NS = Not Shown

Italicized text = Not included or optional configuration add-ons